

Carepeutic[®]

Shiatsu & Swing Massage cushion

with Heat

KH261



Instruction Manual

IMPORTANT SAFEGUARDS

When using electrical, especially Children are present, basic safety precautions should always be followed including the following:

READ ALL INSTRUCTIONS BEFORE USING.

KEEP THE MANUAL FOR FUTURE PURPOSE.

DANGER-To reduce the risk of electric shock:

- Always unplug the appliance from the electrical outlet immediately after using and before cleaning.
- DO NOT reach for an appliance that has fallen into water. Unplug it immediately.
- DO NOT use while bathing or in shower.
- DO NOT place or store appliance where it can fall or be pulled into a tub or sink.
- DO NOT place in or drop into water or liquids.
- NEVER use pins or other metallic fasteners with this appliance.
- DO NOT fasten the zipper on back of lumbar cushion unless the product is repaired or replaced by manufacturer.

WARNING-To reduce the risk of burns, electrocution, fire or injury to persons.

- An appliance should never be left unattended when plug in. Unplug from outlet when not in use and before putting on or taking off parts or attachments.
- Close supervision is necessary when this appliance is used by or near children, invalids or disabled persons.
- Use this appliance only for its intended use as described in this manual. DO NOT use attachments not recommended by manufacturer or distributor, especially any attachment not provided with the unit.
- NEVER operate this appliance if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or dropped into water.
- Keep cord away from heated surface.
- NEVER use while sleeping or fall asleep while using the massager.
- DO NOT operate where aerosol products are being used or occur and cause fire, electrocution or injury to persons.
- DO NOT carry this appliance by supply cord or use cord as handle.

- To disconnect, turn off the massager and heat, then remove the adaptor from the outlet.
- DO NOT use on an infant or invalid or on a sleeping or unconscious person.
- DO NOT use on insensitive skin or on a person with poor blood circulation.
- DO NOT punch the device.

CAUTIONS:

- Consult your doctor prior to using this product if:
 - You are pregnant
 - You have a pacemaker or other aid.
 - You have any concerns regarding your health.
- Never leave the appliance unattended. Especially if children are present
- We recommend you not to use the massager for more than 15 minutes on a time. Take a break after each cycle of massaging.
- This product is designed to provide personal soothing massage to worn muscles, not for professional use.

- DO NOT use this product as a substitute for medical attention.
- This product should NEVER be used by an individual suffering from any physical ailment that would limit the user's capacity to operate the control or who has sensory deficiencies in the lumbar
- DO NOT use if wet. This product is only for indoor use.
- DO NOT insert pins
- DO NOT use this product with invalids, disabled, and infants.
- DO NOT use this appliance with a person who is sensitive to heat
- This unit should not be used by children or invalids without adult supervision. Adult's supervision is required to make sure children don't play this appliance as a toy.

FEATURE & FUNCTIONS:

Features

1. True massage experience

Advance massage chair technology lets you get an amazing spa massage where you are.

2. Shiatsu, Swing & Rolling massage

Four independent rollers traveling up and down your back in shiatsu massage, swing massage, or rolling massage style.

3. Advanced microprocessor control

With state-of-the-art touch panel handheld controller, six programs for your choices of full, upper, or lower back massage in shiatsu massage or rolling massage style.

4. Command track.

With a touch of a button, you can adjust the width of the rollers to comfortably fit your body.

5. Fits most chairs.

Integrated strapping system transforms an ordinary chair into a massage chair.

Product Specification

- Product dimension: 110*45*13cm, Folded: 70*28cm
- Input: 12VDC, 2.5A
- Power: 30W

Strapping System

This back massager incorporates a unique strapping system which allows you to fasten it to most ordinary chair or auto seat. Set the cushion in your seat and adhere the elastic straps firmly around the seat back. Your massager won't slip or slide around.

For use in Home or Office

Plug adaptor into an AC outlet and plug in the receptacle end into the input jack, located along the side of the cushion. Attach the massage cushion to any chairs for a luxurious massage at home or in office.

For use in the car

Simply plug the 12 Volt auto adaptor into a cigarette outlet and plug the receptacle end into the input jack, located along the side of the cushion. Slip the massage cushion straps over your seat to enjoy a relaxing massage as you drive.

Maintenance & Storage

Storage:

Place massager in its box or in a safe dry and cool place. Avoid contact with sharp edges or objects. To avoid breakage, DO NOT wrap the power cord.

To Clean

- Turn off the massager and heat, and unplug the adaptor and allow it to cool down before cleaning. Clean only with a soft, slightly damp sponge. Never allow water or any other liquids to come into contact with the massager.
- DO NOT immerse in any liquid to clean
- NEVER use abrasive cleaners, brushes, gasoline, kerosene glass/ furniture polish or paint thinner to clean.

How to protect the mechanism:

- Do NOT lie flat on the cushion or sit upright on the part of kneading mechanism.
- Make sure you use the cushion in a right way, put it on a chair, and sit down on the seat cushion, and then lean against the back cushion for massaging.
- Do NOT try to lie flat on floor or use it as a mattress on floor.
- The maximum weight capacity is 250 lbs.

Function



Heat: You can switch functions in addition to the massage heat. Press the button and the thermal heat activated (LED lamp is lit) by pressing the button, the heat function disabled (LED lamp goes off).

Shiatsu Massage & swing : Here you have the following settings
Selection : Full back / upper back / lower back.
The point massage feature, you can look at the convenient time for
Choose a massage area and hold it

Rolling massage: The following settings have you in the role of massage
Selection: Full back / upper back / lower back.
In addition, you can choose massage width / spacing role.
The pleasant massage for you, you can adjust width by the
Press the " button set width " .

Seat: The vibration massage in the seat and thigh area is done by 2 powerful motors, it provides 3 different intensity settings available (Low / Medium / High)

ON / OFF - button: Lets you turn on and off the massage cushion

Troubleshooting:

Turn On/Off power:

- After plug in the power cord to wall outlet, the kneading board will travel up and down for 3 seconds to initiate the device. After initiation, you can press the Power button on controller to turn on the massager.
- After turning off the power on controller, the kneading board will continue to travel up and down for 10 seconds and then stop completely.

Noise level:

- The standard of noise level for shiatsu and swing back massager is 60db. This massager has 55db noise level, which is acceptable.
- The noise level can be measured by a sound meter. Keep the sound meter 30cm away from the massager and check its noise level.

Limited Warranty

Please contact seller for warranty. Limited warranty from manufacturer only for original purchaser against defect related to manufacturing or workmanship under normal use. Due to the hygiene or rehabilitation nature of this product, it is non-returnable.

KH261

Made In China

Distributed by Q.L.M.

Carepeutic® is a registered trademark

All rights reserved. © Q.L.M.

www.ideaTomorrow.com