



www.voltheat.com

INSTRUCTIONS & OPERATION MANUAL

Thank you for choosing your Volt heated product to help you stay warm. As with any electrical device, it is important to follow instructions to avoid damage to the product, yourself or your property. Failure to follow instructions may cause overheating, fire or injury. Please read product labels and all instructions before using your Volt heated product.

Before using your 3v Volt product the battery(ies) should be fully charged. Please follow the instructions below on how to use and maintain your battery(ies).

1. Remove battery(ies) from packaging.
2. Plug the 3v charger into a properly rated AC electrical outlet.
3. Connect the 3v battery(ies) to the output plug(s) from the 3v charger. Do not force the plug into the battery. It is normal for the plug not to entirely enter the battery . The LED light(s) on the battery(ies) will light up indicating it is receiving a charge.
4. Battery(ies) will be fully charged when all 4 LED's on the battery show solid green. This can take between 3-5 hours.
5. Disconnect the charged 3v battery(ies) from the charger output plug(s).
6. Locate the input plug(s) on your Volt heated product and connect to charged battery. The plug can be found in a small pocket on the side of the socks/slippers and usually inside a small zippered pocket on garments.
7. Press "power" button on battery(ies) to turn "ON". Press "power" button again to select desired power level . NOTE: Battery will not turn "ON" unless connected to the product.

CAUTION

Your 3v Volt Heated Product should only be used with a 3v Volt Heated Battery. Never connect your 3v Volt Battery with any non 3v Volt Heated product regardless of how similar the plugs may look, may feel, or appear to fit or work together.

POWER STATUS (Optional VB350 Battery Only)

You can check the power status of the battery by disconnecting the battery from the product and holding down the power button. The LED lights will light up indicating power status. All 4 lights indicates the battery is charged, 3 lights indicate 75%, 2 lights indicate 50% , 1 light indicates 25% and flashing lights indicates the battery needs to be charged.

RECHARGEABLE BATTERY SYSTEM CARE

WARNING: Do not use battery if you notice a change of shape (lumps), over-heat when charging or if rust or corrosion on the battery connectors is found.

- Failure to charge battery prior to use will reduce battery life.
- CHARGE BATTERY REGULARLY. Charge between each use and a minimum of once every 3 months. It is important to maintain at least 25% of your battery power when not in use. Failure to do this will result in performance problems and reduced battery life.
- The battery life is 300+ cycles before the battery will diminish in capacity output.
- Lithium batteries provide a diminished capacity output at extreme cold temperatures - keep batteries inside the garment to minimize the impact and improve the performance.

WASH & CARE

Remove battery and store connecting cable in battery pocket. We recommend to spot clean with a damp cloth or hand wash in cold water with mild detergent, hang dry. Do not twist the garment to prevent damage to cable. Do not dry clean or bleach.

WARRANTY

When you purchase your Volt heated product made by H2C Brands,LLC., the electrical components of the product, the battery(ies) and charger are warranted for 90 days from the date of the initial purchase. Please contact www.voltheat.com with any questions or warranty claims. info@voltheat.com