

SHARPER IMAGE®

IONIC 
COMFORT.

Professional Electrostatic Air Purifier
with Permanent Stainless Steel Filter
Model: 203833-01 and 203833-02



USE AND CARE GUIDE

TABLE OF CONTENTS

About Your Sharper Image Ionic Comfort	3
Warnings	4
FCC Information	5
Features and Controls	6
Filters	7
Set-Up and Operation	8
Check Filter Light	8
Check Filter Reminder	9
Stainless Steel Filter Maintenance	9-10
Troubleshooting Guide	11
Questions and Answers	11

About Your Sharper Image® Ionic Comfort

Thank you for purchasing the Sharper Image® Ionic Comfort Electrostatic Air Purifier. We are dedicated to making your life cleaner and healthier with creative solutions that combine superior quality with the very latest technology.

The Sharper Image® Ionic Comfort provides fresher, cleaner air for you to breathe and saves you money at the same time by eliminating the need for expensive replacement filters. With a revolutionary quiet fan system, advanced ionic cleaning and patented high efficiency filter design, your Sharper Image® Ionic Comfort helps remove common pollutants such as dust, pollen and tobacco smoke from your air, along with smaller, more dangerous atomic sized particles that traditional HEPA air purifiers can leave behind. And, because it's whisper quiet, the Sharper Image® Ionic Comfort can be placed in any room in the house – even your bedroom.

Your Sharper Image® Ionic Comfort has been thoroughly tested to meet our own exacting quality control standards. Please take a few moments to review the following important information before using it.

SAVE THESE INSTRUCTIONS



REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK - DO NOT USE THIS PRODUCT WITH ANY SOLID STATE SPEED CONTROL DEVICES.

Failure to the following warnings may result in electrical shock, burns, fire or injury:



WARNING

GENERAL SAFETY INFORMATION

The power cord is equipped with a three-prong grounded plug that must be inserted into a matching receptacle. Under no circumstances must the grounding prong be cut off the plug. Where a two-prong wall receptacle is encountered, it must be replaced with a properly grounded three-prong receptacle installed in accordance with the National Electrical Code (NEC) and all applicable local codes and ordinances. This work must be done only by a qualified electrician, using copper wire only. The Blue Plug™ on your air purifier is a safety feature. It contains a non-replaceable safety device (fuse) that should not be removed or tampered with. To reduce the risk of fire, electric shock and personal injury, DO NOT attempt to remove, replace, repair or tamper with the originally supplied plug. If the Air Purifier has stopped functioning, it may be due to the safety device incorporated in this plug. Discard product if the attachment plug is damaged. To reduce the risk of fire, electric shock and personal injury, DO NOT remove, replace, repair or tamper with the originally supplied plug. **WARNING: DO NOT USE A THREE-PRONG TO TWO-PRONG ADAPTER. IMPROPER CONNECTION MAY CREATE THE RISK OF ELECTRICAL SHOCK. USE OF SUCH ADAPTERS IS NOT PERMITTED IN CANADA.**

1. Make certain the power source conforms to the electrical requirements of the Product.
2. Make certain that the room is equipped with a working smoke detector.
3. Use this Product only as described in this manual. Any other use not recommended by the manufacturer may result in injury to persons or damage to property.
4. To reduce the risk of personal injury and electric shock, the Product should not be played with or placed where small children can reach it.
5. Unplug power cord before moving the Product.

DO NOT DEPEND ON THE ON/OFF SWITCH AS THE SOLE MEANS OF DISCONNECTING POWER WHEN MOVING THE PRODUCT. ALWAYS UNPLUG THE POWER CORD. ALWAYS TURN OFF THE PRODUCT BEFORE LEAVING THE AREA. NEVER LEAVE CHILDREN UNATTENDED WHEN THE PRODUCT IS ON OR PLUGGED IN.

6. DO NOT use Product in or near a window. Rain may create an electrical hazard.
7. Completely assemble Product according to instructions before connecting to power supply.
8. Avoid the use of extension cords because the extension cord may overheat and cause a fire. Do not plug Product into any other cord connected device, such as a power strip, cord reel, surge protector, multiple outlet adapters or outlet-type air fresheners. The use of such devices may create a fire hazard.
9. NEVER operate any Product with a damaged cord or plug, or if the Product has been dropped or damaged in any manner.
10. NEVER insert or allow fingers or foreign objects to enter any ventilation or exhaust opening as it may cause an electric shock, fire, or damage the Product. To reduce the risk of fire, DO NOT block or tamper with the Product in any manner while it is in operation.
11. Always place the Product on a stable, flat, level surface when operating to avoid the chance of the Product overturning. It is recommended for floor use only. Locate the Power Cord so the Product or other objects are not resting on it. Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Do not route cord under furniture or appliances. Arrange cord away from traffic areas and where it will not be tripped over.
12. This Product is not intended for use in wet or damp locations. NEVER locate a Product where it may fall into a bathtub or other water container. NEVER use Product where flammable liquids are used or stored.
13. Care should be taken so that objects do not fall and liquids are not spilled into the enclosures.
14. NEVER use Product outdoors
15. This Product is not suitable for use in agricultural facilities including areas where livestock, poultry or other animals are confined. Please refer to National Electric Code (NEC) Article 547-7 (2008), or applicable state or local codes or standards relating to electrical requirements for Agricultural Buildings. THIS PRODUCT DOES NOT MEET THE REQUIREMENTS OF NEC ARTICLE 547-7 (2008).
16. This Product is not suitable for use in hazardous locations. Please refer to National Electric Code (NEC) Article 500 or applicable state or local codes or standards relating to electrical requirements for Hazardous locations. THIS PRODUCT DOES NOT MEET THE REQUIREMENTS OF NEC ARTICLE 500 (2008).
17. **REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK - DO NOT USE THIS PRODUCT WITH ANY SOLID STATE SPEED CONTROL DEVICES.**



DANGER

Failure to the following warnings may result in electrical shock, burns, fire or injury:

- DO NOT remove the covers or back panel. There are no user serviceable parts inside. "Dangerous voltage" within the unit's enclosure may be of sufficient magnitude to constitute a risk of electric shock.
- DO NOT disassemble or attempt to repair the unit. Incorrect repair can cause risk of electric shock or injury to persons when the unit is used.
- DO NOT expose this unit to wet, damp, rain or moisture locations.
- This Product must NOT be used in potentially dangerous locations such as flammable, explosive, chemical-laden or wet atmospheres where gasoline, paint, flammable liquids or vapors are used or stored.
- DO NOT operate where aerosol units are being used or where oxygen is being administered. Do not operate this unit in oxygen rich environments.
- DO NOT rub your fingers or hand along the stainless steel Filter Plates - THE EDGES ARE SHARP!
- Do not immerse entire air purifier unit in water or other liquid.
- Do not reach for air purifier unit that has fallen into water. Unplug it immediately.
- The unit should be situated away from heat sources such as direct sunlight, radiators, heat registers, stoves or other heat-producing appliances.
- Never block the air openings of the unit with materials, such as clothing, plastic bags or papers. Do not place it on a soft surface, such as a bed or sofa where the air openings may be blocked. Keep the air openings free of lint and hair.
- Do not carry this unit by its cord or use the cord as a handle.



CAUTION


- Remove all packing materials (bags, cardboard, foam, etc.) prior to operating this unit.
- Do not allow children to play with any plastic bags that accompany this unit. Plastic bags are a hazard to young children.
- Close supervision is necessary when this unit is operated near children.
- Do not allow children to play with this unit. This unit is not a toy.
- Use this unit only for its intended use as described in this manual.
- Make sure that the filters are completely dry before placing back into the unit after cleaning.
- Unplug this unit during lightning storms or when unused for long periods of time.
- For indoor use or operation only.
- Use correct electrical supply voltage as indicated on the bottom label of the unit.
- Turn the unit off before unplugging from an electrical outlet.
- Do not touch the stainless steel filter plates or wire after removing the filter. A small amount of static charge may still be present if the unit was recently turned off.
- Inspect the stainless steel filter plates after each cleaning to ensure that the stainless steel plates are not bent and touching each other. Performance may suffer if the stainless steel plates touch each other.
- The filter assembly contains two parts that are washable. Follow the maintenance instructions included in this manual before attempting to clean.
- Plastic or rubber parts, like the feet on this product may stick to surfaces and/or hardwood floors. The product may leave a residue that could darken, stain or leave permanent blemishes on the finish of certain surfaces.
- A small amount of ozone may be produced during the ionization process. This unit strictly complies with the U.S. guidelines set for acceptable ozone emission levels. Any person suffering from heart, lung or respiratory illness should consult his or her physician before using this unit. If you use a pacemaker, it is important that you turn the unit off before cleaning the filter cartridges.

FCC INFORMATION


This unit complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.

Features and Controls Main Unit



Permanent Stainless Steel Filter Assembly



Setting Up the Unit


1. Remove unit from carton.
2. Remove all packaging and tape from unit.

IMPORTANT:

- Remove and discard the foam packing block from inside the filter door. The unit must be placed on a level surface, and there must be a minimum 24" (60cm) clearance from anything around the unit. Ensure that the air intake grill and air exit grill are not blocked.

Operating the Unit

1. Plug the power cord into an energized electrical wall outlet.
2. The power button will illuminate when it is pressed to turn the unit on.
3. Select the desired speed by rotating the variable speed control.
4. Press the Power Button again to shut the unit off.



Check Filter Warning

1. The Check Filter LED will blink rapidly when the Permanent Stainless Steel Filter Assembly is removed and until it has been properly re-installed.
2. If the Permanent Stainless Steel Filter Assembly has not been re-installed properly into the unit, the Check Filter light will continue to blink. Remove the filter and confirm that no object may have fallen in and may be preventing the filter from being re-installed properly.

Filter Cleaning Reminder

- The Check Filter LED Light illuminates to alert you when the Stainless Steel Filter needs to be checked for cleaning.
- The light is programmed to illuminate after set intervals of time.
- Depending on the air quality in your environment, it may be necessary to clean your filter more or less frequently than the Check Filter Light indicates. Constant Arcing is the best indication that the filter is in need of cleaning.

To extinguish the light:

1. Press the Power Button once so the unit shuts off.
2. Next, hold down the Power Button for 5 seconds. You will see the Check Filter Light flash for 3 seconds. Your timer has now reset.

Stainless Steel Filter Maintenance

⚠ CAUTION

- Caution must be used when handling or cleaning the stainless steel filter as the ionizer wire may break with excessive applied pressure.
- Inserting a wet filter into the unit may permanently damage the electrical components!
- The air quality will affect how frequently the filter must be cleaned. The stainless steel filter may be machine washed in a dishwasher or manually in a sink or tub.

Stainless Steel Filter Assembly cleaning procedure:

1. Press the Power Button to shut the unit off.
2. Unplug the unit from the receptacle outlet.
3. Open the Filter Door and remove the Stainless Steel Filter Assembly by firmly gripping the Filter Handle and pulling the assembly out of the unit.
4. Remove Honeycomb Pre-Filter from Stainless Steel Filter Assembly prior to cleaning.

Dishwasher Cleaning

Remove the Honeycomb Pre-Filter from the bottom of the Stainless Steel Filter Assembly and place both components on the bottom tray of your dishwasher. Wash the filters as you would dishes. If you find that the filter's Stainless Steel Filter Plates do not get completely clean with one wash cycle, increase the wash cycle time or wash the Filters a second time. Note that some phosphate-free dishwasher detergents can cause staining to the aluminum filter-frame. Staining will not affect performance. If in doubt, use water-only cleaning or clean in sink. The normal dishwasher drying cycle should be an effective drying time.

Note:

Do not allow the dishwasher rack to bend the Stainless Steel Filter Plates or break the Ionizer Wire. Care must be taken when positioning in the dishwasher. Your air purifier will not function properly if the Stainless Steel Plates touch each other or the Ionizer Wire breaks.

Stainless Steel Filter Maintenance (Continued on Page 10)

Stainless Steel Filter Maintenance (Continued)

Sink Cleaning

Remove the Honeycomb Pre-Filter from the Stainless Steel Filter Assembly and place both components in your sink. Rinse to remove large debris. Submerge both filters in warm water that contains standard dish washing soap. Allow the filters to soak for at least 15 minutes, drain the sink and rinse the filters with cold water.

5. Allow the Stainless Steel Filter and Honeycomb Pre-Filter to dry completely before inserting them back into the unit. The filter can be dried in the dishwasher or air-dried. Typically, evaporative air drying can take 12-24 hours, depending on humidity and temperature.
6. Install the Honeycomb Pre-Filter back into the bottom of the Stainless Steel Filter Assembly. Don't worry: both ends are the same, so it can be inserted either way. Never operate the unit without the Honeycomb Pre-Filter.
7. Insert the cleaned and dried Stainless-Steel Filter Assembly back into your Sharper Image® Ionic Comfort unit. If you have reinstalled the Stainless Steel Filter Assembly after cleaning and drying, and hear "crackling" after turning it on, your filter is still wet. Turn the unit off, remove the Filter Assembly and allow it to dry longer.

Troubleshooting Guide

Issue:	Resolution:
Crackling sound is heard:	<ol style="list-style-type: none"> 1. The Filter Assembly needs to be cleaned. Refer to the section on Stainless Steel Filter Maintenance. 2. Filters are not completely dry after cleaning. Remove the filters from the unit and let them completely dry until the crackling stops. 3. Foreign material is caught between the Stainless Steel Filter Plates. Turn off and unplug the unit then carefully remove debris making sure not to bend the plates.
A "Hissing" sound is heard or; Cleaning Performance seems low:	<ol style="list-style-type: none"> 1. After prolonged use, the unit's Ionizer Wire may become dirty. This may result in poor ion generation and the possibility of a "Hissing" sound coming from the unit's Ionizer Wire. If this occurs, wash the Filter Assembly as described in the section on Stainless Steel Filter Maintenance.
Unit will not Turn On:	<ol style="list-style-type: none"> 1. Ensure that the Filter Assembly is properly inserted and the unit is properly plugged into an energized wall outlet.
Ionizer Wire is broken:	<ol style="list-style-type: none"> 1. Call Customer Service for a replacement. The unit will not operate with a broken Ionizer Wire. Never replace this wire with anything but approved components supplied by the manufacturer.

Questions and Answers

Questions:	Answer:
How often is cleaning of the Stainless Steel Filter Assembly required?	The Check Filter LED Indicator illuminates to alert you when the Stainless Steel Filter Assembly needs to be checked for cleaning. It may be necessary to clean the Filter Assembly more frequently depending on the air quality in your environment.
Can I leave my Sharper Image® Ionic Comfort on continuously?	Yes. It is safe and economical to leave on as long as you like - even 24 hours per day, 365 days per year.
Will my Sharper Image® Ionic Comfort interfere with home or office equipment (e.g. computers)?	No. The Sharper Image® Ionic Comfort meets FCC regulations for harmful interference with radio communications so you may place your Sharper Image® Ionic Comfort by your computer, audio players, etc. without causing any unusual interference problems.
Will the Stainless Steel Filter wear out over time?	No. The Stainless Steel Filter Assembly is made of high quality corrosion resistant stainless steel. Be careful not to bend the plates. If the plates touch each other, the electrostatic filtration will be impaired. Note that some phosphate-free dishwasher detergents can react with aluminum and cause staining. It's recommended to try water-only cleaning first if washing filter in dishwasher.

CUSTOMER SERVICE:

Have a Question? Need a Part?

**Contact Sharper Image Customer Service:
1-877-206-7866 Monday-Friday 9AM - 6PM ET.**