

IMPORTANT SAFETY INSTRUCTIONS

WHEN USING AN ELECTRIC FURNISHING, ESPECIALLY WHEN CHILDREN ARE PRESENT, BASIC SAFETY PRECAUTIONS SHOULD ALWAYS BE TAKEN, INCLUDING THE FOLLOWING:

READ ALL INSTRUCTIONS BEFORE USING THIS FURNISHING

DANGER — TO REDUCE THE RISK OF ELECTRIC SHOCK: ALWAYS UNPLUG THIS APPLIANCE FROM THE ELECTRICAL OUTLET BEFORE CLEANING.

WARNING — TO REDUCE THE RISK OF BURNS, FIRE, ELECTRIC SHOCK, OR INJURY TO PERSONS:

1. Unplug from outlet before putting on or taking off parts.
2. Close supervision is necessary when this furnishing is used by or near children or individuals with certain disabilities.
3. Use this furnishing only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.
4. Never operate this furnishing if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or dropped into water. Return the furnishing to a service center for examination and repair.
5. Keep the cord away from heated surfaces.
6. Never drop or insert any object into any opening.
7. Do not use outdoors.
8. Do not operate where aerosol (spray) products are being used or where oxygen is being administered.

9. To disconnect, turn all controls to the OFF position, then remove plug from outlet.
10. Never operate the furnishing with the air openings blocked. Keep the air openings free of lint, hair and the like.
11. To protect against electrical hazards, do not use while bathing or in the shower.
12. **Be sure mirror is not in a position where it can reflect sunlight; reflected sunlight can cause a fire.**
13. Do not use on a soft surface, such as a bed, where openings may be blocked.
14. Turn mirror OFF, allow the unit to cool and unplug cord before storage or cleaning.
15. Do not place or store this furnishing where it can fall or be pulled into a tub or sink.
16. If this furnishing falls into water, unplug it immediately. **Do not reach into the water.**
17. Never use while sleeping.
18. Do not leave appliance unattended when it is plugged in.
19. Plug the adapter into the main outlet after checking that the voltage matches the listed technical data for the main outlet to be used (Input: 100-240V AC 50/60Hz, Output: 5.0V DC 1000mA). The adapter is intended to be correctly oriented in a vertical or floor-mount position. For connection to a power supply not in the USA, use an attachment plug adapter of the proper configuration for the power outlet.
20. This appliance is not toy. Keep away from children.



FOR HOUSEHOLD USE ONLY

SAVE THESE INSTRUCTIONS


OPERATING INSTRUCTIONS

CAUTION: BE SURE DIRECT SUNLIGHT DOES NOT STRIKE MAGNIFYING SIDE OF MIRROR WHEN LEFT UNATTENDED; REFLECTED SUNLIGHT CAN CAUSE FIRE.

1. The mirror can only be operated with the adapter. Plug the adapter into any standard wall outlet.
2. Quickly press switch cap to control light in the 1x mirror frame. One press for low setting, two for medium setting, and three for high. A fourth press will turn off the light. You can have both the mirror frame light and the blue mood light at base on at the same time.
3. Press and hold switch cap for 1½ to 3 seconds to control blue mood light in base. Press once and hold to turn light on, press twice and hold for gentle pulsating mode; press and hold for 3 seconds to turn off the light.
4. Long press on the switch for more than 3 seconds can turn off all lights at the same time.



Press 1 time for low setting, 2 times for medium setting, 3 times for high setting, 4 times to turn off. Press and hold switch cap for 1½ to 3 seconds for mood light on base. Press and hold 1 time for on, press 2 times and hold for pulsating mode; press and hold for 3 seconds to turn off.



FCC MARKINGS

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION: Any changes or modifications not expressly approved by Conair Corporation, the manufacturer of the product and the party responsible for compliance, could void the user's authority to operate the equipment.

Special Feature

This lighted makeup mirror uses energy-saving, lifetime LED bulbs. Replacement bulbs are not required.

STORAGE

Disconnect from electrical outlet. BE SURE DIRECT SUNLIGHT DOES NOT STRIKE MAGNIFYING SIDE OF MIRROR WHEN LEFT UNATTENDED; REFLECTED SUNLIGHT CAN CAUSE FIRE. Allow to cool to room temperature before storing. Place in a cool, dry area out of reach of children, where it will not be damaged.

MAINTENANCE

Your lighted mirror is designed for household use and is virtually maintenance free. No lubrication is needed.

If cleaning becomes necessary, disconnect the appliance from the power source and wipe exterior with a cloth. Clean mirror surfaces with a glass cleaner. Do not light until you are certain mirror is completely dry to protect against electrical hazards. If any abnormal condition occurs, unplug the lighted mirror, allow it to cool, and return it to an authorized service center for repair.

Handle cord carefully for longer life; do not jerk or strain at plug connections, or wrap cord around mirror for storage. This could cause damage to the cord and the mirror could short circuit. To store mirror, coil cord loosely.

**WARNING:
IF YOU THINK
THE POWER IS
OFF WHEN THE
SWITCH IS OFF,
YOU'RE WRONG.**

KEEP AWAY FROM WATER



Everybody knows that electricity and water are a dangerous combination. But did you know that an electrical appliance is still electrically live even if the switch is off? If the plug is in, the power is on. So when you are not using your appliances, keep them unplugged.

**ALWAYS UNPLUG
SMALL APPLIANCES**

LIMITED ONE-YEAR WARRANTY (U.S. AND CANADA ONLY)

Conair will repair or replace (at our option) your unit free of charge for 12 months from the date of purchase if the appliance is defective in workmanship or materials.

To obtain service under this warranty, return the defective product to the service center listed below, together with your purchase receipt and \$5.00 for postage and handling. California residents need only provide proof of purchase and should call 1-800-326-6247 for shipping instructions. In the absence of a purchase receipt, the warranty period shall be 12 months from the date of manufacture.

ANY IMPLIED WARRANTIES, OBLIGATIONS, OR LIABILITIES, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED IN DURATION TO THE 12-MONTH DURATION OF THIS WRITTEN, LIMITED WARRANTY. Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you.

IN NO EVENT SHALL CONAIR BE LIABLE FOR ANY SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED, WHATSOEVER. Some states do not allow the exclusion or limitation of special, incidental, or consequential damages, so the above limitation may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state.

For info on any Conair product, call 1-800-326-6247 or visit us on the web at www.conair.com

Service Center
Conair Corporation
Service Department
7475 North Glen Harbor Blvd.
Glendale, AZ 85307

©2017 Conair Corporation
Model BEMLRG/BEMLRQG
17PM031528

IB-15386

illuminations
LED MOOD LIGHT



CONAIR

For your safety and continued enjoyment of this product,
always read the instruction book carefully before using.
Models BEMLRG/BEMLRQG