


XY4+ Quick Start Guide

Please read all instructions carefully, and if you have any questions, you may contact XY Findables technical support at support@xyfindit.com.

This setup guide is for XY4+ model XY Finders. Please begin by verifying that the model you're using is XY4+ using the photo below.



Your XY4+ will have a button with an XY logo on the front.

On the back, it will have four tiny holes for the sound system and a large number 4 in one corner.

Once you have verified that your XY Finder is an XY4+, please download the XY Find It app. XY Find It is available for Android (such as Samsung, Motorola, LG, HTC, Lenovo, and Sony) and iOS (Apple) devices.

Note: Android devices must have Android 4.4.4 or higher to run XY Find It, and Apple devices must have iOS 9 or higher. XY Find It is not compatible with phones (other than Apple) that use their own proprietary operating systems, such as Windows Phone, Blackberry, Amazon, and Huawei.



Setting up XY Find It on an Android device:

1. To download XY Find It for Android, please open the Play Store app on your Android device and search for "XY Find It", then tap on the INSTALL button.

Before proceeding, please make sure you have BLUETOOTH and LOCATION services turned on.


2. When the app is finished downloading, tap on OPEN. If you are asked to allow XY Find It to use your phone's location services, please tap on ALLOW.
3. If you have not yet created an XY Find It account, tap on JOIN in the bottom left corner.
4. Enter your information, making sure everything is correct. When you're done, tap on JOIN at the bottom of the screen.
5. You will now see a screen showing a map with your location represented by a blue dot. Tap on the '+' icon in the top right corner of the screen.

6. Tap on Claim Your XY4.
7. Press and hold the XY logo button on your XY Finder until the finder beeps. The app will say "Finder Detected" near the bottom of the screen, and then move to a new screen.
8. Tap on where the app says "What will you attach XY to?" and enter the name of the object you're going to attach your XY Finder to, such as "keys" or "wallet".
9. Then you may tap on the camera icon and take a photo of the item. (If asked to allow XY Find It to use your camera or media files, please tap on ALLOW.)
10. Tap on SAVE when you're ready to save your XY Finder.

The photo and name of your XY Finder will show along the bottom of your screen on the left side. Its location will show on the map. You may now use your XY Finder.

11. To test your XY Finder, tap on the photo of it, then tap on FIND IT in the bottom right corner. This will beep your XY Finder. Press on STOP where the Find It button was to stop the beeping.

If you press the XY button on the XY Finder, itself, it will ring your phone. Press FOUND IT in the XY app or a volume button on your phone to stop the ringing.



Setting up XY Find It on an Apple device:

1. To download XY Find It for iOS on an iPhone, please open the App Store app on your Apple device, search for "XY Find It", and tap on "Get."

Important: If you are using an iPad, after searching for "XY Find It" please click on the drop-down menu that says "iPad Only" in the top left corner and switch it to "iPhone Only." Then repeat your search. When XY Find It appears, tap on the "Get" icon.

Before proceeding, please make sure you have BLUETOOTH and LOCATION services turned on.

2. When the app is finished downloading, tap on OPEN.

If you are asked to allow XY Find It to use your phone's services, please tap on ALLOW.

3. If you have not yet created an XY Find It account, tap on JOIN in the bottom left corner.

4. Enter your information, making sure everything is correct. When you're done, tap on JOIN at the bottom of the screen. You will now see a screen showing a map with your location represented by a blue dot.

5. Tap on the '+' icon in the top right corner of the screen.

6. Tap on XY4.
7. Press and hold the XY logo button on your XY Finder until the finder beeps. The screen will load, then move to a new screen.
8. Tap on where the app says "What will you attach XY to?" and enter the name of the object you're going to attach your XY Finder to, such as "keys" or "wallet".
9. Then you may tap on the camera icon and take a photo of the item. (If asked to allow XY Find It to use your camera or media files, please tap on ALLOW.)

Tags are an advanced feature, there's no need to worry about entering anything in that field. If you don't wish to use them, please simply skip this step.

10. Tap on the checkmark in the top right corner when you're ready to save your XY Finder.
11. The photo and name of your XY Finder will show along the bottom of your screen on the left side. Its location will show on the map. You may now use your XY Finder.
12. To test your XY Finder, tap on the photo of it, then tap on FIND IT in the bottom right corner. This will beep your XY Finder. Press on STOP where the Find It button was to stop the beeping.

If you press the XY button on the XY Finder, itself, it will ring your phone. Press FOUND IT in the XY app or a volume button on your phone to stop the ringing.

Hints and Tips for Optimal Use:

This model of XY Finder is not a GPS device. It is a Bluetooth device, meaning it is a short-distance item finder that works using a low-strength radio signal. Your phone uses its own GPS to remember the last place where this signal was detected.

It is for use with objects that may be misplaced or that need to be found indoors. It is not intended for use with moving objects, for tracking items long distance, or as an anti-theft device.

Please check on your XY Finder from time to time and press its button to make it beep. The battery may need to be changed occasionally, so a little bit of simple maintenance will help keep everything running smoothly. XY4+ Finders use a single CR3032 lithium battery, available most places where batteries are sold.

If you have any questions or need any technical assistance, please contact us at support@xyfindit.com.