


# SHARPER IMAGE®

## EXTRA BATTERY FOR CORDLESS AUTO STOP TIRE INFLATOR

Item No. 206672

User Guide



Thank you for choosing the Sharper Image Extra Battery for Cordless Auto Stop Tire Inflator. Please take a moment to read this guide and store it for future reference.

### INSTRUCTIONS

- Remove the existing battery on the Cordless Auto Stop Tire Inflator.
- Connect the Extra Battery onto the Cordless Auto Stop Tire Inflator.
- Plug the extra battery into your car cigarette lighter.

*Note: You must use the charger that came with your Cordless Auto Stop Tire Inflator. A charger is not included with this item.*

### SPECIFICATIONS

- Battery type: Lithium battery capacity: 2200mAh
- Working voltage: 11.1-12V
- Charge time: 4 hours

### WARNINGS

- Keep the device away from rain or fire.
- Keep away from children.

### WARRANTY / CUSTOMER SERVICE

Sharper Image branded items purchased from SharperImage.com include a 1-year limited replacement warranty. For Customer Service, please call +1 (877) 210-3449.

**SHARPER IMAGE®**

The SHARPER IMAGE® name and logo are registered trademarks.

©Sharper Image. All Rights Reserved.