

# SHARPER IMAGE®

## PORTABLE VACUUM CLEANER

Item No. 206915

### User Guide

Thank you for purchasing the Sharper Image Portable Vacuum Cleaner. Please take a moment to read this guide and store it for future reference.

## IDENTIFICATION OF PARTS



## HOW TO USE:

The cigarette lighter plug connects directly to the cigarette lighter of your automobile.

1. Power Switch: Turn on/off
2. Filtration system: Double filtration system, filter element can be washed and reused
3. Quick Dust Removal Cover: Dust Removal Cover can be opened after rotation
4. Dust Storage Separation Switch: Press Separable Dust Storage Warehouse

## USE OF ACCESSORIES:



1. Extension Pipe: Direct Connection with Host, Extension Function
2. Flat nozzle: Can connect the main engine and extension pipe. Used to clean narrow gaps, etc.
3. Brush: It can connect the main engine and extension pipe for cleaning seats, central console, footpads, etc.

## WARNINGS:

1. DC12V Voltage Input only
2. Discontinue use at 30 minute intervals to prolong the life expectancy of the device
3. Clean the filter and dustbin components regularly

## **SPECIFICATIONS**

- Set includes: Vacuum cleaner x 1/Extension Pipe x 1/flat nozzle x 1/brush x 1
- Product size: 320\*135\*10MM
- Main material: ABS
- Filter material: HEPA
- Rated voltage: DC12V
- Peak power: 120W /Working power: 80W
- Max vacuum degree: 6000PA
- Cable: 4.5M
- Fuse: 10A

## **WARRANTY / CUSTOMER SERVICE**

Sharper Image branded items purchased from SharperImage.com include a 1-year limited replacement warranty. If you have any questions not covered in this guide, please call our Customer Service department at 1 [877] 210-3449. Customer Service agents are available Monday through Friday, 9:00 a.m. to 6:00 p.m. ET.

**SHARPER IMAGE®**

The SHARPER IMAGE® name and logo are registered trademarks.

©Sharper Image. All Rights Reserved.