


SHARPER IMAGE®

EXTRA BATTERY FOR CORDLESS AUTO STOP TIRE INFLATOR

Item No. 207145

User Guide



Thank you for choosing the Sharper Image Extra Battery for Cordless Auto Stop Tire Inflator. Please take a moment to read this guide and store it for future reference.

INSTRUCTIONS

- Remove the existing battery on the Cordless Auto Stop Tire Inflator.
- Connect the Extra Battery onto the Cordless Auto Stop Tire Inflator.
- Charge the extra battery with your vehicle's cigarette lighter.

Note: *You must use the charger that came with your Cordless Auto Stop Tire Inflator. A charger is not included with this item.*

SPECIFICATIONS

- Battery type: Lithium-ion
- Battery capacity: 2200mAh
- Working voltage: 11.1V-12V
- Charge time: 4 hours

WARNINGS

- Keep the device away from rain or fire.
- Keep away from children.
- This might damage the fabric.

WARRANTY / CUSTOMER SERVICE

Sharper Image branded items purchased from SharperImage.com include a 1-year limited replacement warranty. If you have any questions not covered in this guide, please call our Customer Service department at 1 (877) 210-3449. Customer Service agents are available Monday through Friday, 9:00 a.m. to 6:00 p.m. ET.

SHARPER IMAGE®

The SHARPER IMAGE® name and logo are registered trademarks.

©Sharper Image. All Rights Reserved.