

Under Arm Toner Replacement Gel Pads Instructions Sheet

1. Remove the protective film from each pad and place it in a safe area. (Do not tear or destroy the Plastic film)
2. Place each gel pad over each of the metal prongs (on the Strap) the Mesh side of the Gel pad should be facing down, make sure the Black side is facing outward.
3. Once you have completed your session place the protective film back on each gel pad
4. Store in a dry place.

For Re-Orders:

visit www.igia.com