



Insta-Sleep Self INFLATING MATTRESS



For better protection of this product, never unfold or inflate the airbed in temperatures below freezing, avoid extensive exposure to the sun and protect from contact with sharp objects and rough ground. Make sure to handle the pump with care. Avoid pounding and jumping to prevent damage to the airbed material.

Setup Operations: (Before inflating, Plug into AC Power outlet.)




Turn NeverFlat Dial to desired firmness level.




Turn Inflate/Deflate Switch clockwise to "Inflate" position to turn on Setup Pump and inflate air bed.
Setup Pump will automatically turn off upon reaching selected firmness level and Inflate/Deflate Switch will automatically return to "Off" position.


NeverFlat Pump Operations



NeverFlat Pump is a fully automatic pressure maintenance pump that is designed to operate silently so that it will not disturb your sleep when it automatically turns on to reinflate. Pump will automatically turn on when air pressure inside air bed drops below a predetermined low pressure level. Pump will automatically turn off upon reaching selected firmness level (firmness determined through adjusting the NeverFlat Dial).




To ensure that NeverFlat Pump will operate, please make sure to plug power cord into 120V AC electrical wall socket.




To turn off NeverFlat Pump auto inflate function; turn NeverFlat Dial to "Off" position. NeverFlat Pump will not automatically turn on regardless of air pressure inside air bed.

Takedown Operations:



Turn NeverFlat Dial to "Off" position so NeverFlat Pump will not automatically turn on.



Turn Inflate/Deflate Switch counterclockwise to "Deflate" position for complete air removal. Upon complete air removal, Setup Pump will automatically turn off and Inflate/Deflate Switch will automatically return to "Off" position. Place power cord into Cord Storage Pocket for storage.