

USER'S MANUAL

KITCHEN SET

HW67658

THIS INSTRUCTION BOOKLET CONTAINS **IMPORTANT** SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.

Please give us a chance to make it right and do better!

Contact our friendly customer service department for help first.

Replacements for missing or damaged parts will be shipped ASAP!

Follow Costway



Contact Us!

Do NOT return this item.

Contact our friendly customer service department for help first.



Before You Start

Please read all instructions carefully and keep it for future reference.

General Security Warning

Caution: The Product is not suitable for the children under 3 years

Danger: Keep all small parts and packaging materials for this product away from babies and children, otherwise they may pose a choking hazard.

















Danger: Lack of attachment may cause a risk of tipping.




WARNING:
CHOKING HAZARD-Small parts.
Not for children under 3 years.

Warning for Assembly


- ⚠ Construction only by adults
- ⚠ Remove all Packaging, separate and count all parts and hardware.
- ⚠ Read through each step carefully and follow the proper order.
- ⚠ We recommend that, where possible, all items are assembled near to the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.
- ⚠ Ensure a secure surface during construction, and place the product always on a flat, steady and stable surface.

Ax12 	Ix3 	Bx4  4x14mm	Jx3 
Cx4  3.5x16mm	Kx3 	Dx36  3x10mm	Lx2 
Ex29  4x35mm	Mx2 	Fx11  4x20mm	Nx3 
Gx6 	Ox1 	Hx2 	Px1 




Assembly Instruction

1




STEP 1:
 Assemble parts I to No.3
 and No.11 with screws D.
 Assemble No.20 to
 No.11 with screws B.


2



STEP 2:
 Assemble part O to No.7
 with screws B and parts
 L to No.7 with screws C.


3


4




STEP 4:
Insert wooden plugs A to
No.2, 4, 5, 12.


5




STEP 5:
Assemble No.11 to No.1 with
screws E, and attach No.5 to
No.11, then assemble No.3 to
No.1 with screws E.

6



STEP 6:
Assemble No.2 to No.1 with
screws E.

7



STEP 7:
Assemble No.4 to No.3 with
screw E. Insert No.9 to No.3
and No.11.

8


STEP 8:
Assemble No.17 to No.1
with screws E. Then attach
No.12 to No.11 and No.17.

9


STEP 9:
Assemble No.6 to No.1 with
screws E.

10



STEP 10:
Insert No.9 to No.3 and
No.6, also insert No.13 to
No.11 and No.17.

11



STEP 11:
Assemble No.7 to No.3, 6,
11 with screws E.

12


STEP 12:
Assemble No.8 to No.7 and
No.11 with screws E.

13

STEP 13:
Attach No.14 to No.11 and
No.17 with screws E.




STEP 14:
Insert No.15 to No.11 and
No.17.




STEP 15:
Assemble No.16 to NO.11
and No.17 with screws E.

16



STEP 16:
Assemble No.10 to No.6
with screws D.

17



STEP 17:
 Assemble No.18, 19 to
 No.17 with screws D. Put
 part P above No.7.

Welcome to visit our website and purchase our quality products!

With your inspiring rating, COSTWAY will be more consistent to offer you
EASY SHOPPING EXPERIENCE, GOOD PRODUCTS and EFFICIENT SERVICE!

US office: Fontana, California

UK office: Ipswich



- * Reward Points
- * Exclusive Customer Service
- * Personalized Recommendations
- * Permanent Shopping Cart
- * Order History

5 Star Rating



We would like to extend our heartfelt thanks to
all of our customers for taking time to assemble
this product and giving us valuable feedbacks.

THANK
YOU
☺

