








NOTE:





- Read all instructions before starting
- Do not tighten using power tools
- No additional tools required
- Do not completely tighten any bolts until the unit is fully assembled and sitting on a level surface



DESCRIPTION




NO.	PART LIST	Q.TY
A	 Seat	1PC
B	 Legs	4PCS
C	 Middle Leg	2PCS


NO.	HARDWARE	Q.TY
1	 8x60 Bolt	12 PCS
2	 8.5x20x2 Washer	8 PCS
3	 6x20 Screw	4 PCS
4	 M4 Allenkey	1 PC

ASSEMBLY INSTRUCTION


STEP 1




STEP 2



STEP 3



STEP 4



Refer to www.patiowise.com for assembly video on the product page for Curved Wooden Bench

Thank you for purchasing this product. With some simple care and maintenance, you'll be able to enjoy this product for many years.

This product has been treated with an oil based sealer. If used outdoors, we recommend re-sealing this product with an oil-based water-proof sealer each season to increase it's life expectancy and maintain it's original look. Cover this product or move it indoors during harsh weather to prevent excessive weathering.

Warnings!!

- Use care when assembling or moving this product to avoid personal injury
- Always check for cracks or damage before using. If any are detected DO NOT USE
- Always make sure bench is placed on level surface
- Never sit down hard on bench
- Never stand on bench
- Never jump on bench
- Never lean back on bench
- Maximum weight is 440 LBS. Never exceed that weight
- Do not use bench when under the influence of alcohol or drugs
- Seller is not responsible for any injuries that may occur when using this bench

Warranty:

- Limited one year Warranty due to manufactures defects
- For technical questions or troubleshooting, please email **service@patiowise.com**