


NOTE:

- Read all instructions before starting
- Do not tighten using power tools
- No additional tools required
- Do not completely tighten any bolts until the unit is fully assembled and sitting on a level surface



Refer to www.patiowise.com for assembly video on the product page for Balcony Rail Planter

Thank you for purchasing this product. With some simple care and maintenance, you'll be able to enjoy this product for many years.


This product has been treated with an oil based sealer. If used outdoors, we recommend re-sealing this product with an oil-based water-proof sealer each season to increase it's life expectancy and maintain it's original look. Cover this product or move it indoors during harsh weather to prevent excessive weathering.

Warnings!!


- Use care when assembling or moving this product to avoid personal injury
- Always check for cracks or damage before using. If any are detected DO NOT USE
- Make sure product is secure and fastened tight when on rail.
- Never use product unless a secure connection to deck railing is certain.
- Never lean, stand, sit or apply any weight to planter box other than its intended use for plants and herbs.
- DO NOT attach to your railing facing outside your deck. Ensure rail planter faces the interior of your deck space
- Do not assemble rail planter when under the influence of alcohol or drugs
- Seller is not responsible for any injuries that may occur when using this bench

Warranty:

- · Limited one year Warranty due to manufactures defects
- For technical questions or troubleshooting, please email **service@patiowise.com**




COMPONENT LIST A 1 Pc B 1 Pc 1 Pc 1 Pc 2 Pcs EE 2 Pcs 2 Pcs




Assembly Instructions

Refer to https://www.patiowise.com/product-page/balcony-planter-box




Determine which length (E) or (EE) you want to use here.

Step 3



Notice placement of wood tongue. It is not center. When sliding into the groove in step 5, the short side is down.



Notice placement of wood tongue. It sits flush to one side and not the other

