GAME INSTRUCTIONS

HOW TO PLAY:

Once the unit is turned on, the game will light-up. The timer on the game will begin once the sensor under the rim is triggered. Once the game begins the unit will score until the time runs out (after 60 seconds). During this time each player will shoot at their rim. Once the time runs out, the game is over and the player with the highest score will be the winner!

Note:

We welcome you to use your own balls on this set. Please note, the scoring sensor may not pick up darker colored balls.

Both players can score 2 points per shot during the first 45 seconds. When there is 15 seconds remaining each player can score 3 points per shot.

YOU ARE NOW READY TO PLAY!

Made In China Franklin Sports Inc. Stoughton, MA 02072



For replacement parts: Visit: franklinsports.com/instructions Email: parts@franklinsports.com Call: 1-800-225-8649



Ages 6+

2 PLAYER PRO HOOPS **LED BASKETBALL**

ITEM NUMBER: **54337**





⚠ WARNING: CHOKING HAZARD--Small parts. Not for children under 3 yrs.



CUSTOMER SERVICE COMMITMENT

Thank you for purchasing this Franklin® product! In the event that the product you've purchased has missing or damaged parts, please contact us at:

parts@franklinsports.com

Visit our website at: franklinsports.com/instructions

If possible, please include product part number and parts description so we can best assist you.


WE'RE HERE FOR YOU!

PLEASE DO NOT RETURN THIS PRODUCT TO THE STORE IT WAS PURCHASED FROM.

WE ARE COMMITTED TO FULFILLING ALL REPLACEMENT PART NEEDS IMMEDIATELY.

Thank you for your continued support, and welcome to the #FranklinFamily!

PARTS LIST




2


ASSEMBLY INSTRUCTIONS

GENERAL NOTE

- 1. Find a clean place to begin the assembly of your Pro Hoops Basketball Game.
- 2. Remove all the parts from the box and verify that you have all of the listed parts as shown on the parts list page.
- 3. Before assembling the set, remove the protective film from the front of the backboard.





Requires 3 "AAA" size batteries (not included). Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable batteries.



- NOTE -


Locate the battery compartment on the back of the Main Board (#1) and insert (3) "AAA" Alkaline Batteries (not included).






NOTE -


Attach the Hooks (#6) to the Main Board (#1) using six M4 Metal Bolts (#3) and six M4 Metal Nuts (#4). Stick the Protective Foam (#13) to the inside faces of the hooks.






- NOTE -


Attach the Rims (#7) to the Main Board (#1) using four Bolts (#5), two Metal Supports (#2) and four Nuts (#9).





NOTE -Install the Nets (#8) onto each Rim (#7).







Inflate your Basketballs (10) using the Inflation Pump with Needle (11) that's included.

- NOTE -

To find the needle in the pump, simply open the top cap as shown, take the needle out of this compartment (Figure 1), and screw into the bottom of the pump (Figure 2).



Franklin* ITEM#: 54337



3