

INSTALLATION METHODS



1: Open the cover



2: Align the small shafts on both sides of shoe film with the slots on both sides of the dispenser and put it down



3: Pull out the shoe film and lay it flat on the sponge pad of the shoe film dispenser, then close the cover.

Note: the side with glue of the shoe film is upward, so as to stick to the shoe sole.

HOW TO USE THE DISPENSER

4: Step on the shoe film, pull your foot back along with the shoe film until it reaches the black pedal (Attention: no pulling the shoe film too long, make sure the film is tight when cutting otherwise it will affect the result cutting). Step on black pedal to cut off the shoe film.



AUTOMATIC SHOE FILM DISPENSER INSTRUCTION



Dear customers

Thank you for choosing and trusting our product——shoe film dispenser.

Shoe film dispenser is a new product with strong practicability and wide application. It is not only used in house, but also widely used in hotels, hospitals, factories, labs, clean room, museums, show homes, animal and plant cultivation and research sites etc.

This product does not need power, and it is safe and reliable, exquisite.

No need to take off shoes when using it and easy to change the shoe film.

CORRECT USE OF SHOE FILM DISPENSER

