SHARPER IMAGE®

Note: Please long press TALK/LCD button 3 seconds to turn on the unit. Hold MODE and TALK/LCD button 3 seconds to enter power-saving mode.




Features

- LCD tells time, weekday, month, year.
- With clear "Talking" function.
- With alarm & snooze functions.
- With hourly report function.
- 12/24 hour systems selection.
- LCD can be totally turned off and the watch remained a pure analog looking.



Change LCD Mode

Press the 【MODE】 button to change modes in following sequence:



Activate the Voice

Press the [TALK /LCD] button to activate the voice information.


Display the time and date

In time display mode, press 【SET/HR RPT.】, it displays the year.

Press [SET/HR RPT.] again, it displays the month and date. Press [SET/HR RPT.] again to return to normal time display.

Set the Time

- In time display mode, press the 【MODE】 button once to enter time setting mode. At this time "Hour" will flash and "Time Set, Hour Set" will be announced. Press the 【ADJ/ALARM】 button to adjust correct hour.
- Press the 【SET/HR RPT.】 button, "Minute" will flash, and "Minute set" will be announced, Press the 【ADJ/ALARM】 button to adjust correct minute.
- 3. Repeat step 2 to set time format, year, month and day.



Adjust the Analog Watch Hands

Pull out the stem and turn it until the analog time matching the LCD time. Push the stem back to its original position to restart the timekeeping.

Turn ON/OFF LCD

Hold the 【TALK/LCD 】 button for two seconds to turn on/ off LCD.

Note

When LCD is turned off, all buttons except $\[TALK/LCD\]$ are not functioning.

Set Alarm Time

- 1. In time display mode, press the 【MODE】 button twice to enter Alarm time setting mode. On the screen, "AL.SET" will display and "Alarm set, Hour Set" will be announced. At this time, "Hour" will flash. Press the 【ADJ/ALARM】 button to adjust correct hour.
- Press the [SET/HR RPT.] button. "Minute" will flash, and "Minute set" will be announced. Press the [ADJ/ALARM] button to adjust correct minute.

Remarks:

- 1. If no button is pressed for 30 seconds during random setting, the screen will automatically return to time display mode.
- 2. Hold the 【ADJ/ALARM】 button to quickly adjust the value during setting.

Turn ON/OFF Alarm and Oversleeping Alarm (Snooze)

In Time-display mode, to turn on the alarm, repeatedly press 【ADJ/ALARM】 until you hear "Alarm on" and the announcement of alarm time, and "﴿ " appears. To turn on the snooze function, repeatedly press 【ADJ/ALARM】 until you hear "Snooze on" and the announcement of alarm time and "SNZ" appears. To turn off the alarm, repeatedly press 【ADJ/ALARM】 until you hear "alarm off". "﴿ " and "SNZ" disappear. At the preset alarm time, the alarm sounds for 30 seconds. To silence the alarm sooner, press any key; then, if snooze is on, the alarm will repeat three times in every five minutes.

Turn ON/OFF Hourly Report

This watch supports all-day hourly report. In time display mode. Hold down the 【SET/HR RPT.】 button until "((•))" being displayed and "HOURLY REPORT ON" is announced.

Hold down [SET/HR RPT.] button until "((•))" being disappeared and "HOURLY REPORT OFF" is announced.

Replace Battery

This watch is powered by CR2025 lithium battery. If LCD becomes dark, sound becomes weak or function is not correct, you should replace battery according to the following steps:

- 1. Remove four screws on the cap with a screwdriver.
- 2. Remove old battery and install new one. Please note the "+" polarity should face upward.
- 3. Install the cap, and fix screws.

The analog watch part is powered by one LR626 button cells, if the hands cannot work normally, please follow the steps to replace the battery

- 1. Remove four screws on the back cap with a screwdriver.
- Remove CR2025 battery first, and then remove old LR626 battery (as per the illustration shown).
- 3. Install one new LR626 button cells with "+" polarity facing up.
- 4. Replace CR2032 battery and fix the cap with screws.