

SHARPER IMAGE®

TRAVEL SLEEP SOUND MACHINE WITH ALARM

Item No. 204865

Owner's Manual

Thank you for purchasing the Sharper Image Travel Sleep Sound Machine with Alarm. Please read this guide carefully and keep for future reference.



Power Sources

Your unit is powered by an AC ADAPTER [included] or by 4 "AA" batteries [not included]. Your unit is easily convertible for international use since it includes a dual voltage, interchangeable plug adapter.

AC Power & International Use Your unit includes a global adapter that allows you to electrically power your unit in different countries. To use, choose the plug that fits your particular wall outlet and slide it onto the adapter.

Connect the AC ADAPTER to the AC ADAPTER JACK and plug the AC ADAPTER into a wall outlet. When plugged in, the unit will draw no power from any batteries that you may have installed in the unit's BATTERY COMPARTMENT.

Battery Power

To install batteries, open the BATTERY COMPARTMENT. Insert 4 "AA" alkaline batteries in the direction marked by the indicators inside the BATTERY COMPARTMENT. Replace the BATTERY COMPARTMENT door.

Note: It is recommended that you keep 4 "AA" batteries installed in your unit at all times. These 4 "AA" batteries will not only power your unit during travel or when a wall outlet is not within reach, but

they will provide back-up power in the event that a power outage occurs while the unit is plugged into a wall outlet.

Note: Without any AC or Battery Power, your unit will maintain time, calendar, sound and alarm settings for 1 minute. This is particularly useful when changing batteries.

Setting Clock/Alarm

Dual Time Home/Travel Button: Your unit has 2 time selections – HOME time and TRAVEL time. You can conveniently alternate between your everyday [HOME] time and a travel [TRAVEL] time by simply pressing the HOME/TRAVEL button, without having to reset your time display. You may also set alarms to sound on either the HOME or TRAVEL times.

For Example: If you live in New York and travel to London, you can conveniently keep your New York time as your HOME time and the local time in London as your TRAVEL time. You may set your alarm to wake up at your selected New York HOME time or your local London TRAVEL time.



To Set Clock & Calendar

1. Make sure that the TRAVEL LOCK button is set to the UNLOCKED position.
2. Select your preferred time selection [HOME or TRAVEL] by pressing the HOME/TRAVEL button.
3. To set the clock for the location currently displayed, press and hold the TIME SET button, for 2 seconds. A single beep will confirm entering the Time Set mode and the hour digits will flash on the screen to signify that you are in the Time Set mode.
4. Press either the UP [+] or DOWN [-] buttons to set Hours.
Note: The AM and PM Indicator is visible beside the Minute digits.
5. When your desired Hours setting is reached, press the TIME SET button to store the Hours and move to the Minute digits.
6. Repeat steps 4 and 5 until you have selected all of your clock and calendar settings [Hours, Minutes, Year, Month, Day and 12 or 24 Hour Time Display].
7. Press the TIME SET button to exit the Clock and Calendar Setting mode.

To Set Alarm Time, Nature/Voice Sound & Alarm Volume:

1. Make sure that the TRAVEL LOCK button is set to the UNLOCKED position.
2. Select your preferred time selection [HOME or TRAVEL] by pressing the HOME/TRAVEL button.
3. Enter the alarm time set mode for the location displayed by pressing and holding down the ALARM SET button, for 2 seconds. A single beep will confirm entering the alarm set mode and the hour digits will flash on the screen to signify that you are in the Alarm Set mode.
4. Press either the UP [+] or DOWN [-] buttons to set the Hours for your alarm time.
5. When your desired Hours setting is reached, press the ALARM SET button to store the Hours and move to the Minute digits.
6. Press either the UP [+] or DOWN [-] buttons to set the Minutes for your alarm time. When the desired Minutes setting is reached, press the ALARM SET button to store the Minutes and move to the Set Alarm Sound mode.
7. In the Set Alarm Sound mode select your NATURE/VOICE alarm sound by pressing either the UP [+] or DOWN [-] buttons until the desired sound is shown

on the display – the selected sound will play during this selection process. When you have chosen your desired sound, press the ALARM SET button to enter the Set Alarm Volume mode.

Note: If you want to wake to a beeping alarm, please see the Alarm On/Off section.

8. Select your alarm volume by pressing the UP [+] button to increase alarm volume [to a maximum volume of 20], or the DOWN [-] button to decrease the alarm volume [to a minimum volume of 01].
9. After selecting your alarm sound volume, exit the Alarm Time, Sound and Volume Setting mode by pressing the ALARM SET button.
10. If desired, turn the unit over and turn the TRAVEL LOCK switch to the locked position to ensure that time, calendar, sound and alarm settings are not changed if the buttons are accidentally bumped during travel.

Alarm On/Off

To select a beeping or NATURE/VOICE alarm sound, first select the time location [HOME or TRAVEL]. Then Press the ALARM SET button repeatedly to scroll through the available choices: ALARM BEEP, ALARM SOUND, and ALARM OFF, until you reach your selection.

The display menu abbreviations correspond to the following:

- [HOME/TRAVEL] ALARM BEEP - Selects a Beeping Alarm
- [HOME/TRAVEL] ALARM SOUND - Selects a Nature/Voice Alarm
- [HOME/TRAVEL] ALARM OFF - Turns the Alarm Off

When ALARM BEEP is “on”, the word BEEP and an ALARM BELL is visible on the display. When ALARM SOUND is “on”, the word SOUND and an ALARM BELL are visible on the display. When ALARM OFF is selected, there is no BEEP, SOUND or ALARM BELL visible on the display.

Follow the above procedure for each of your desired time selections [HOME or TRAVEL].

Alarm Check

You can conveniently check your alarm time, alarm sound and alarm volume by pressing the ALARM CHECK button. Pressing the ALARM CHECK button will display the alarm time, your selected alarm type, and play back your selected alarm for 4 seconds at the set volume for first the HOME, then the TRAVEL alarms.

Travel Lock

A TRAVEL LOCK switch is located on the back of the unit. By sliding the switch to the locked position, you will ensure that all of your time, calendar, alarm and sound settings do not change, even if the buttons are accidentally pressed inside your luggage. Make sure that you slide the TRAVEL LOCK switch back to the unlocked position when you want to make any time, calendar, alarm or sound selection changes.

On/Off and Sound Selection

To turn your unit's sound playback "On" or "Off", press the SOUND ON/OFF button. When first turned ON, the unit will automatically play its factory sound setting – 01 OCEAN SURF. To select a different sound, press either the UP (+) or DOWN (-) until the sound of your choice appears on the screen and is played back. Note: The SOUND ON/OFF button also allows you to repeat your last played sound at the same volume and timer setting.

For Example: You are listening to the OCEAN SURF sound at half volume on the 60-minute timer position. After the timer automatically turns the unit off after 60 minutes, pressing the SOUND ON/OFF button will automatically repeat the entire sequence by playing back the OCEAN SURF sound at half volume for another full 60-minute period. As summarized below, your unit incorporates eighteen (18) nature sounds digitally recorded in the wild by one of the world's foremost nature recorders, one (1) jet lag reduction sound, and one (1) voice memo playback sound selection [please see Voice Memo Recording and Playback].

- 1. Ocean Surf:** The ocean surf provides a calm rhythm that helps you drift off to sleep and creates a relaxing Oceanside environment.
- 2. North Woods:** Peaceful songbirds take you to a secluded forest for relaxation or contemplation.
- 3. Thunderstorm:** Unwind to the exhilarating, but soothing sound of distant thunder as gentle rain falls upon a remote lake.
- 4. White Noise:** The steady flow of a cascading waterfall is perfect as a "natural white noise" for masking unwanted background sounds.
- 5. Night Train:** Picture yourself on a steam engine train as it cuts through the still night lulling you to sleep with its pulsating sounds.

6. Spring Rain: A tranquil rainfall provides a peaceful setting for relaxation and sleep. The rain sound is particularly good at masking higher-toned background noise.

7. Island Surf: Enjoy the calming sound of surf from the shore of a sun-drenched tropical island as seabirds call while gracefully soaring overhead.

8. Bonfire: During the still of a wilderness night, enjoy the solitude and warmth of a roaring bonfire with mesmerizing, glowing embers.

9. Stream: A rippling mountain stream helps you unwind and creates an excellent background sound for daily activities in the home or at the office.

10. Hidden Cove: Discover the tranquility of soft surf as it washes against a sandy beach within a hidden cove protected by towering cliffs.

11. Wind: Nestle in as a powerful, but calming windstorm blows through a deep mountain valley.

12. Asian Garden: Relax or meditate in a secluded Asian Garden where the lulling sounds of an Asian Sarod blend with a gently flowing brook.

13. Song Birds: Experience the peacefulness of a joyful songbird rhapsody.

14. Harbor Swell: Picture yourself alongside a boat-filled harbor as waves gently lap against the shore and boats creak as they rock against their moorings in a brisk breeze.

15. Bamboo Chimes: Lie back and let the gentle sound of bamboo wind chimes help remove the stress of daily life.

16. Summer Night: Tree frogs take you to a Pacific forest for a placid summer's night of relaxation and contemplation.

17. Cooling Fan: Sleep to the continuous whirling sound of an electric fan without the chilling effect of the real thing.

18. Rain Forest: Enjoy the peacefulness of a sparkling mountain stream as exotic jungle birds search the adjoining foliage for fruit and insects.

19. Jet Lag: When used during flight or upon reaching one's destination, this sound can help reset one's internal body clock. This safe, patent pending technique works as follows: Drifting, "non-linear" music which does not conform to expected musical formulas is combined with slowed nature sounds, other natural sounds, and special pulse-rates to help slow the body's rhythms and encourage relaxation that has been shown effective in resetting the body's inner clocks and transcending time-zone related jet-lag symptoms.

20. Voice Memo: Play back any personal message that you record (up to 15 seconds in length).

Note: Sound #20 Voice Memo, will not show up on the display as an available playback sound until you have recorded a voice memo message.

Voice Memo Recording and Playback

Your unit includes a handy voice memo-recording feature that allows you to record a single message up to 15 seconds in length.

To Record a Memo

1. Press and hold down the MEM button.
2. Upon hearing a beep, speak towards the front of the unit from about 12"/30cm away.
3. Recording will start when the display shows REC MEMO 15sec and starts counting down in one second increments from 15 seconds towards 0, thereby indicating how long your message is and how much time you have left.
4. When you are finished recording your message, release the MEM button and message recording will stop. The unit will automatically stop recording when 15 seconds has been reached.

To Playback a Memo

Select it as the playback sound [#20 Voice Memo], or as your HOME or TRAVEL alarm sound.

Note: You can only record one message for playback. Sound #20 [Voice Memo] will not show up on the display as an available playback sound until you have recorded a voice memo message.

Volume Control

To select sound playback volume, rotate the VOLUME CONTROL dial.

30, 60, or 90 Minute Timer

Your unit has 4 timer options: 30, 60, 90 minutes or Continuous playback. On the "30", "60" and "90" minute timer positions, the sound gradually fades away during the last 15 minutes before the unit turns itself off.

To select the length of time you want your sound to be played, follow these steps:

1. Press and hold the SOUND ON/OFF button for 2 seconds. The unit will beep and show you the status of

the timer on the display: Timer Off, Timer 30min, Timer 60min, or Timer 90min.

2. Press either the UP [+] or DOWN [-] buttons to choose your desired timer length.

3. After reaching your desired timer length, press the SOUND ON/OFF button again and your chosen timer selection will be visible on the clock display to the right of the time.

Note: If your alarm is turned ON and you listen to nature sounds in the continuous mode, your unit will automatically turn your selected nature sound "Off" when the beep alarm sounds. If you had selected a nature sound alarm sound different from the one you listen to in continuous mode, as a wake-up alarm sound, your unit will turn "Off" the continuously played sound and play the alarm sound.

Snooze

Your unit includes a 15 minute "snooze" feature. You may activate the SNOOZE cycle by pressing the SNOOZE/LIGHT button once while the alarm is sounding. The alarm will stop immediately, "snooze" for 15 minutes, and then turn on again. This cycle is repeated 2 times before the alarm turns off automatically.

The display will conveniently show you how much time remains in the snooze cycle by counting down the snooze cycle starting with "Snooze 15min".

Back Lighting

When your unit is powered by 4 "AA" batteries, pressing the SNOOZE/LIGHT button once will activate the back lighting on the clock. Once activated, the backlight will stay lit for 5 seconds.

When your unit is AC powered [i.e. plugged into a wall outlet], the backlight will remain on, but at a lower brightness level, so you can see the time in the dark but not be disrupted by light that is too bright. When the SNOOZE/LIGHT button is pressed, the brightness level will return to normal brightness for 5 seconds, and then return to the lower brightness level.

When an alarm sounds, the back lighting will activate for 60 seconds when the unit is battery powered, or get brighter for 60 seconds if AC powered.

Headphone Use

For listening to sounds in private, your unit includes a HEADPHONE JACK (headphones not included). The headphone jack accepts a 1/8" (3.5mm) monaural plug.

Reset Button

Should you ever experience problems with the proper function of your unit, you may need to reset the unit's computer controlled electronics. To do so, take a small pointed object (e.g. the end of a paper clip) and push the RESET button located within the BATTERY COMPARTMENT. This will reset all time, calendar, alarm and recorded memo settings.

Back Up Battery

Your clock uses a CR2032 coin cell battery for back up, located in a slide on the bottom of the unit. This battery will hold your settings while you replace your primary batteries or if there is a power outage when the unit is plugged in.

Replacing the backup battery

1. Push in on the locking tab of the slide.
2. Insert a fingernail or screwdriver gently into the slot above the backup battery slide.
3. Pull out the back up battery slide using your fingernail or screwdriver, while pushing the locking tab out of the way.
4. Insert a new CR2032 coin cell battery with the positive side of the battery facing up, matching the positive marking on the slide.
5. Reinsert the battery slide into the clock in the correct orientation. Please properly dispose of the CR2032 coin cell battery in accordance with your local regulations.

FCC Notice

This equipment complies with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. Operation is subject to the following two conditions: [1] This device may not cause harmful interference; and, [2] This device must accept any interference received, including interference that may cause undesired operation.

Customer Service

Sharper Image branded items purchased from SharperImage.com include a 1-year limited replacement warranty. If you require any assistance with your Travel Sleep Sound Machine with Alarm, please call 1 (877) 210-3449.

SHARPER IMAGE®

The Sharper Image® name and logo are registered trademarks. Manufactured and marketed by Camelot SI, LLC under license. ©Sharper Image All Rights Reserved.

QUICK START GUIDE

STEP BY STEP HOW TO USE THE TRAVEL SLEEP SOUND MACHINE WITH ALARM



Follow these steps to use your Travel Sleep Sound Machine with Alarm

Step 1: Make sure that the TRAVEL LOCK button is set to the UNLOCKED position. Select your preferred time selection [HOME or TRAVEL] by pressing the HOME/TRAVEL button.

Step 2: Enter the alarm time set mode for the location displayed by pressing and holding down the ALARM SET button, for 2 seconds. Press either the UP [+] or DOWN [-] buttons to set the Hours for your alarm time.

Step 3: When your desired Hours setting is reached, press the ALARM SET button to store the Hours and move to the Minute digits.

Step 4: Press either the UP [+] or DOWN [-] buttons to set the Minutes for your alarm time. When the desired Minutes setting is reached, press the ALARM SET button to store the Minutes and move to the Set Alarm Sound mode.

Step 5: In the Set Alarm Sound mode select your NATURE/VOICE alarm sound by pressing either the UP [+] or DOWN [-] buttons until the desired sound is shown on the display. When you have chosen your desired sound, press the ALARM SET button to enter the Set Alarm Volume mode.

Step 6: Select your alarm volume by pressing the UP [+] button to increase alarm volume or the DOWN [-] button to decrease the alarm volume.

Step 7: After selecting your alarm sound volume, exit the Alarm Time, Sound and Volume Setting mode by pressing the ALARM SET button.