

SHARPER IMAGE®

WARMING FOOT MASSAGER

Item No. 205761

User Guide



Thank you for purchasing the Sharper Image Warming Foot Massager. Please read this guide carefully and keep for future reference.

- We recommend you not use the massager for more than 15 minutes at a time.
- Never use this product directly on swollen or inflamed areas or skin eruptions.
- This product is a non-professional appliance designed to provide soothing massage to tired muscles.
- DO NOT use this product as a substitute for medical attention.
- This product should NEVER be used by an individual suffering from any physical ailment that would limit the user's capacity to operate the control or who has sensory deficiencies in the lumbar.
- DO NOT use if wet.
- DO NOT insert pins.
- DO NOT use this product with disabled people or infants.
- This unit should not be used by children without adult supervision.

CUSTOMER SERVICE / WARRANTY

Sharper Image branded items purchased from SharperImage.com include a 1-year limited replacement warranty. If you have any questions not covered in this guide, please call our Customer Service department at 1 (877) 210-3449. Customer Service agents are available Monday through Friday, 9:00 a.m. to 6:00 p.m. ET.

SHARPER IMAGE®

The SHARPER IMAGE® name and logo are registered trademarks.
©Sharper Image. All Rights Reserved.

Thank you for purchasing the Sharper Image Warming Foot Massager. Please take a moment to read these instructions carefully and store for future reference.

OPERATION



POWER: Connect the included AC adapter to the 12VDC input jack in the control panel. Plug the other end into an AC outlet.

HEAT button:

Slide to "I" to start heating.

Slide to "0" to turn off heating.

MESSAGE button:

Slide to "I" to set low massage intensity.

Slide to "II" to set high massage intensity.

Slide to "0" to turn off massage.

This Warming Foot Massager provides a gentle and invigorating massage and improves blood circulation. Place the appliance on the floor in front of your chair. Sit down, relax and place your feet inside the unit. The incorporated heating warms up your feet in a pleasant manner while massaging. **Note:** *The heat function may also be used without the massage.*

STORAGE

Place unit in a dry and safe place. Avoid contact with sharp edges or pointed objects which might cut or puncture the fabric. Do not wrap power cord around the unit. Do not hang the unit by power cord.

MAINTENANCE

- Do not dry clean.
- To clean the outer lining, make sure the massager is unplugged. Wipe the outer surface with a damp, clean cloth. Do not use any strong chemical cleaners.

DANGER: TO REDUCE THE RISK OF ELECTRIC SHOCK:

- DO NOT reach for an appliance that has fallen into water. Unplug it immediately.
- DO NOT use while bathing or in shower.
- DO NOT place or store appliance where it can fall or be pulled into a tub or sink.
- DO NOT place in or drop into water or other liquids.
- NEVER use pins or other metallic fasteners with this appliance.
- Keep dry – DO NOT operate in a wet or moist condition.
- **WARNING:** *To reduce the risk of burns, electrocution, fire or injury to persons:*
- An appliance should never be left unattended when plugged in. Unplug from outlet when not in use.
- Close supervision is necessary when this appliance is used by, on or near children.
- Use this appliance only for its intended use as described in this manual. DO NOT use attachments not recommended by manufacturer.
- NEVER operate this appliance if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or dropped into water.

- Keep cord away from heated surfaces.
- NEVER use while sleeping.
- DO NOT operate where aerosol (spray) products are being used or where oxygen is being administered.
- DO NOT operate under a blanket or pillow. Excessive heating may occur and cause fire, electrocution or injury to persons.
- DO NOT carry this appliance by the supply cord or use cord as handle.
- To disconnect, turn off the massager and heat, then remove the adaptor from the outlet.
- DO NOT use outdoors.
- DO NOT use on an infant or invalid or on a sleeping or unconscious person.
- DO NOT on a person with poor blood circulation.
- DO NOT crush. Avoid sharp folds.
- DO NOT use with a person sensitive to heat without doctor's consultation before use.

CAUTION:

Consult your doctor prior to using this product if:

- You are pregnant.
- You have a pacemaker or other implants.
- You have any concerns regarding your health.
- Never leave the appliance unattended, especially if children are present.
- We recommend you not use the massager for more than 15 minutes at a time.