

# SHARPER IMAGE®

## HEATED SOCKS

Item No. 206134

Owner's Guide

Thank you for purchasing the Sharper Image Heated Socks.  
Please read this guide and store it for future reference.

### FEATURES

- Heated socks with adjustable temperature control – Low, Medium, and High
- Rechargeable lithium-ion batteries [charger included]


### IDENTIFICATION OF PARTS

- A. Sock input plug
- B. Sock pouch
- C. Leg band pouch
- D. Power button/temperature control
- E. Battery charger input plugs
- F. LED light



### OPERATION

1. Remove batteries from box.
2. Plug the battery charger into an outlet.
3. Connect the lithium-ion batteries to the input plugs of the battery charger [Figure 1]. Do not force the plug into the battery.  
*NOTE: The input plug does not sit flush with the battery.*
4. The LED light on the charger will light up in red, indicating that it is being charged.
5. When the LED light on the charger is green, the battery is fully charged [may take up to 5 hours]. *[CONTINUED ON NEXT PAGE]*



## OPERATION (CONT'D)

*NOTE: Before using your Heated Socks, the batteries should be fully charged. Failure to fully charge the batteries prior to their first use may reduce battery life.*

6. When fully charged, disconnect the batteries from the charger.
7. Locate the input plugs on the back of each sock and connect the charged batteries. Place the batteries into the pouch of the sock once connected (Figure 2). The batteries can also be placed into the pouch of the leg bands (Figure 3).



8. Press the power button on the battery to turn on the Heated Socks (Figure 4). The LED light on the battery will turn red. The default temperature when turned on is High.
  - Green: Low heat – 115 °F with approximate run time of 5-6 hours
  - Orange: Medium heat – 131 °F with approximate run time of 4-5 hours
  - Red: High heat – 144 °F with approximate run time of 3-4 hours

*NOTE: Recommended to wear regular socks inside of the Heated Socks. Low or Medium heat is recommended for indoor use at temperatures between 50-64 °F. With lower temperatures (or outdoor use), select Medium or High heat. High heat is not recommended for indoor use for long periods of time, as it may cause overheating and/or bodily discomfort.*

9. The temperature can be adjusted by pressing the power button.
10. To turn off the socks, cycle down to the low heat setting [the LED light will be green]. Press the power button one more time to turn off the socks.
11. Unplug the batteries when the socks are not in use. Store batteries inside the pouch of the socks or leg bands.

*NOTE: The Heated Socks should only be used with the included batteries and charging cable. Never use the batteries or cable with any other device, regardless of how similar the plugs may look, feel, or appear to fit or work together.*



## **CLEANING AND MAINTENANCE**

- Always remove batteries from the socks before cleaning
- Spot clean with a damp cloth or hand wash in cold water with mild detergent
- Hang dry
- Do not twist the garment to prevent damaging the cable
- Do not dry clean or bleach

## **BATTERY WARNINGS**

- Do not use batteries if you notice a change of shape (lumps), overheating when charging, or if rust or corrosion on the battery connectors is found.
- Charge the batteries regularly [recommended a minimum of once every 3 months].
- Charge between each use.
- Maintain at least 25% of the battery power when not in use. Failure to do this will result in performance problems and reduced battery life.
- The battery life is 300+ cycles before the battery will diminish in capacity output.
- Lithium-ion batteries provide a diminished capacity output at extreme cold temperatures; keep the batteries inside the socks to minimize the impact.

## **SAFETY WARNINGS**

- Do not use on open wounds, sensitive skin areas, or in the presence of poor circulation.
- Check skin frequently during use to ensure rashes or burns are not developing.
- The FDA and CPSC recommend the following precautions be taken to avoid hazards associated with the use of heated clothing.

### **ALWAYS**

- Inspect the socks before each use to assure they are in proper working order.
- Discard if they look worn or cracked, or if the electrical cord is frayed.
- Read and follow all instructions prior to use.

### **NEVER**

- Use on an infant.
- Use on a person who is paralyzed or has skin that is not sensitive to temperature changes.
- Use on a sleeping or unconscious person.
- Use in an oxygen enriched environment or near equipment that stores or emits oxygen.
- Sit on this device.
- Crush this device.
- Unplug this device by pulling its connecting cord.
- Use pins or other metallic fasteners to hold this device in place. *[CONTINUED ON NEXT PAGE]*

## SAFETY WARNINGS [CONT'D]

- Do not submerge product or battery into water while in use.
- Do not cut, puncture or tear into the lining of the product.
- Do not allow the battery to have contact with water or other liquids. If water or liquids enter the battery interior, immediately disconnect the product from the battery. Allow the battery to dry completely before use.
- Do not penetrate, strike, short-circuit or disassemble battery.
- Keep all electronic components of your product away from fire and extensive heat.
- Do not leave product unattended while connected to the battery.
- Only use the charger and batteries included with this product.
- If you experience any discomfort while using this product, remove it immediately and consult your physician before resuming use.
- Check with your physician if you have heart disease, a pacemaker, diabetes, circulatory problems, sensitivity to heat, or if you are pregnant or the user is under 13 years of age.

## WARRANTY/CUSTOMER SERVICE

Sharper Image branded items purchased from [SharperImage.com](http://SharperImage.com) include a 1-year limited replacement warranty. For Customer Service, please call +1 [877] 210-3449.

## **SHARPER IMAGE**

The SHARPER IMAGE® name and logo are registered trademarks.  
©Sharper Image. All Rights Reserved.