

Warranty Information:

To fill out your warranty information for your one-year Liteaid product warranty, please visit www.liteaid.com.

Make sure to have the proof of purchase and the item number available.

The Orion 3-in-1 Steamer

LA-125



LITEAID™

New York, NY

Keep this manual for your reference. It is your guide to a safe and efficient operation.

Customerservice@liteaid.com
www.liteaid.com

Product: Orion 3-in-1 Steamer
Model Number: LA-125

Voltage: 110V
Working Time: 18-40 minutes
Capacity: 200ml
Rated Power: 600W


MADE IN CHINA

WARNINGS

1. Do not use the Orion 3-in-1 Steamer in the bath or shower.
2. Keep the Orion 3-in-1 Steamer approximately 9 inches from your skin at all times.
3. Do not put any other substance other than water or vinegar in the steamer.
4. Do not pour water into the unit while the steamer is plugged in or powered on.
5. Do not use if the unit is broken or damaged in any way, or has come in contact with water.
6. Do not place electric cord close to hot objects.
7. Do not use if you feel drowsy, dizzy, ill or are pregnant.
8. Always see a medical professional prior to use if you suffer from any health problems.
9. Be mindful of heat settings. Those with sensitive skin should not use the Orion 3-in-1 Steamer at the maximum temperature.
10. Use in moderation. This product should not be left on while sleeping, or for longer than 40 minutes.
11. Do not attempt to use with voltage other than the voltage specified in the manual.
12. Wipe clean – do NOT wash in washing machines, dryers, or in sinks.
13. Remove the electric plug after using and before cleaning.
14. This is not a toy – this product is not intended for children. Please keep it out of reach of children and animals.
15. Do not attempt to use on animals.
16. Do not use in a wet or damp environment.
17. Only use accessories recommended by the manufacturer.
18. Do not leave the unit plugged in or on when not in use.
19. Do not use the product on infants or those who cannot express their consent.
20. Do not attempt to fix or repair the unit if it is broken.
21. Do not use with an extension cord to avoid damaging the unit.

PRODUCT DIAGRAM

1. Steamer Head
2. Steamer Body
3. Rotary Switch
4. Water Tank
5. Water Reservoir
6. Power Source



Switch Functions:

- Rotate the switch to the function of your choice, a blue light will power on indicating the Steamer has been properly powered on.



USER INSTRUCTIONS

Setting up Your New Steamer:

- Take the Orion 3-in-1 Steamer out of the packaging, making sure to check for damage.

Before connecting the machine to an electrical source:

- Remove water tank from the steamer.
- Pour water into the tank and close the cover tightly. Do not fill tank with any more than 20 ml of water at a time.
- Place the water tank into the water reservoir.

Always make sure to avoid wet surfaces before handling any electrical plug.

- Plug the steamer into the outlet
- Rotate the switch to the function of your choice.

TOWEL WARMER USER INSTRUCTIONS

- Rotate the steamer head counter-clockwise until the arrow is pointed to the unlocking position.
- Remove the steamer head
- Place a folded towel into the steamer body
- Rotate the steamer head clockwise to lock
- Plug in the unit and rotate the switch to the **Warm Towel** position on the knob.
- Dry Towel Warming Time: 7-8 minutes
- Wet Towel Warming Time: 5 minutes
- After desired warming time, turn off unit.
- Open the steamer head and carefully remove hot towel.



Picture 2

FACIAL STEAM USER INSTRUCTIONS

- Adjust the height of the steamer to a proper position for steaming. (Refer to the below picture)
- Rotate the switch to the **Facial Steam** position on the knob.
- In 20 seconds, the Orion 3-in-1 Steamer will begin to send out steam.
- Place your hand 9 inches away from the steam to test the temperature.
- Move your face to the proper position for steaming. (see picture below)
- If you begin to feel dizzy or disoriented while steaming, immediately step away from the unit. Consult a physician before further use.



AIR HUMIDIFIER USER INSTRUCTIONS

- Place the water filled steamer in the applied room that desires humidifying
- Rotate the switch to the humidifier position on the knob.
- Plug in the Steamer

MAINTENANCE

- Heat a solution of 50% water and 50% vinegar inside of the water tank for 15 minutes to remove mineral buildup.
- Unplug the steamer and remove the steamer head as well as the water tank
- Use a towel to remove the bracket inside the steamer. Refer to picture 5.
- Pour clean water into the steamer body and pour out after cleaning.
- Repeat until all mineral buildup is removed.
- Install the towel bracket back to its original position and press until clicked back into place.
- Place and water tank and steamer head back to its original position and store in a cool dry place.



Picture 5