



WARRANTY

Flybar warrants the original purchaser, that the product is free of defects in material and workmanship for a period of one year from the original date of purchase. This warranty does not apply to defects of physical damage resulting from abuse, neglect, improper repair, improper fit, alterations, or use unintended by the manufacturer. If your Flybar Product is found to be defective in materials or workmanship within one year from the date of purchase, Flybar will, at its discretion, either repair or replace the stilt free of charge. Proof of purchase is required. Go to www.flybar.com for complete warranty information.


ABOUT US

In 1918 George Hansburg was inspired to invent the pogo stick. Soon after developing & patenting the original pogo stick, Hansburg brought his idea to personal friend, Florenz Ziegfield, of the world-famous Ziegfield Follies. Ziegfield, the eminent Broadway impresario of the day immediately choreographed a pogo routine into his Follies show.

The Follies made pogo sticks the latest craze and demand went through the roof. To meet the demand, Hansburg opened a factory in NY and 97 years later Flybar continues to be the world's leading pogo innovator and The Original Pogo Stick Company.



Flybar, Inc, Ellenville NY 12428
All Rights Reserved. 2016
www.flybar.com



OWNER'S MANUAL

MSST-B
MSST-Y
MSST-G

WARRANTY

Flybar warrants the original purchaser, that the product is free of defects in material and workmanship for a period of one year from the original date of purchase. This warranty does not apply to defects of physical damage resulting from abuse, neglect, improper repair, improper fit, alterations, or use unintended by the manufacturer. If your Flybar Product is found to be defective in materials or workmanship within one year from the date of purchase, Flybar will, at its discretion, either repair or replace the stilt free of charge. Proof of purchase is required. Go to www.flybar.com for complete warranty information.


ABOUT US

In 1918 George Hansburg was inspired to invent the pogo stick. Soon after developing & patenting the original pogo stick, Hansburg brought his idea to personal friend, Florenz Ziegfield, of the world-famous Ziegfield Follies. Ziegfield, the eminent Broadway impresario of the day immediately choreographed a pogo routine into his Follies show.

The Follies made pogo sticks the latest craze and demand went through the roof. To meet the demand, Hansburg opened a factory in NY and 97 years later Flybar continues to be the world's leading pogo innovator and The Original Pogo Stick Company.



Flybar, Inc, Ellenville NY 12428
All Rights Reserved. 2016
www.flybar.com



OWNER'S MANUAL

MSST-B
MSST-Y
MSST-G

PLEASE READ ALL INSTRUCTIONS CAREFULLY BEFORE USING YOUR MASTER STILTS. KEEP THESE INSTRUCTIONS IN A SAFE PLACE FOR FUTURE REFERENCE.

SOME ASSEMBLY REQUIRED/ MUST BE ASSEMBLED BY AN ADULT!

ALWAYS ADHERE TO THE BELOW AGE AND WEIGHT RESTRICTIONS:

FLYBAR MASTER STILTS - FOR AGES 6 & UP.



4 Adjustable heights for extra fun!

Max: 17' 1/4"

Min: 12' 8/16"

Assembly Instructions:

1. Take out of packaging and make sure all of the parts are present
2. Insert the stilt foot and match up the holes with the holes in the bottom tube.
3. Use the provided bolt and nut to secure it: use the Allen keys to properly tighten the screw into place. Do not overtighten
4. Depress both retaining buttons and insert the top tube in the bottom tube with the curved handles facing inward.
5. Attach the handle, make sure that the handle is in front of the tube and not behind it.
6. Repeat step 4.
7. Now you're all ready to walk on your Master Stilts!

Tips for Walking:

1. When you first begin to get on the Stilt it is recommended to have your back up against a wall so you can balance yourself on the Stilts and not fall over.
2. Make sure that the top of the stilt is underneath your arm the tube is again your shoulder blade; this will give you the most support and balance.
3. Once you are properly standing on the stilts time to walk!
4. When walking put pressure on the handle bar upwards while stepping to give you more control of where you are walking and stability.

PLEASE READ ALL INSTRUCTIONS CAREFULLY BEFORE USING YOUR MASTER STILTS. KEEP THESE INSTRUCTIONS IN A SAFE PLACE FOR FUTURE REFERENCE.

SOME ASSEMBLY REQUIRED/ MUST BE ASSEMBLED BY AN ADULT!

ALWAYS ADHERE TO THE BELOW AGE AND WEIGHT RESTRICTIONS:

FLYBAR MASTER STILTS - FOR AGES 6 & UP.



4 Adjustable heights for extra fun!

Max: 17' 1/4"

Min: 12' 8/16"

Assembly Instructions:

1. Take out of packaging and make sure all of the parts are present
2. Insert the stilt foot and match up the holes with the holes in the bottom tube.
3. Use the provided bolt and nut to secure it: use the Allen keys to properly tighten the screw into place. Do not overtighten
4. Depress both retaining buttons and insert the top tube in the bottom tube with the curved handles facing inward.
5. Attach the handle, make sure that the handle is in front of the tube and not behind it.
6. Repeat step 4.
7. Now you're all ready to walk on your Master Stilts!

Tips for Walking:

1. When you first begin to get on the Stilt it is recommended to have your back up against a wall so you can balance yourself on the Stilts and not fall over.
2. Make sure that the top of the stilt is underneath your arm the tube is again your shoulder blade; this will give you the most support and balance.
3. Once you are properly standing on the stilts time to walk!
4. When walking put pressure on the handle bar upwards while stepping to give you more control of where you are walking and stability.

SAFETY

Use your head—have fun but play safe. Using your Stilts safely is mostly common sense. Always use in front of Adult Supervision.

1. **Check for hazards before you start.** Never walk without first making sure that the surface is safe—solid, flat, clean, well lit, and dry. The best bet: concrete. Stick to outdoor areas that are free of hazards and give you plenty of room to maneuver.

2. **Hazards to watch out for:**

- **Traffic:** Steer clear of streets, parking lots, and other areas vehicles use.
- **Humans:** Using your Master too close to other people is dangerous and rude.
- **Slippery/Uneven Ground:** Don't try to walk on a surface which is wet, oily, or even lightly covered with sand, gravel, leaves, or litter—you'll greatly reduce the traction of your tip.
- **Steep Inclines:** Remember, you want to maintain a position perpendicular to the ground. If the surface slopes sharply, that's just not possible, and it's far more likely you'll skid sideways and fall.
- **Soft or Weak Surfaces:** Don't walk on plank flooring, lawns, or any other inconsistent surface.

USER Guidelines:

- **Check your Master Stilts before first use and on a regular basis.**
- **NEVER use Master Stilts with bare feet. Always wear athletic shoes.**
- **Do not use your Master Stilts without the rubber tips properly in place.**
- **Store your stilts in a dry and sheltered place.**
- **Never use the stilts on a uneven, sloping and wet surface.**
- **Do not modify or remove any original component parts of the Master Stilts.**

Stay within your abilities. With experience and skill, you'll be able to react to pretty much any situation reflexively. But skill develops slowly, so take your time. As you put in the hours, you'll become instinctively aware of how much traction you have, how to correct for balance, and where you're going to walk. Be prepared to bail out at any time.

SAFETY

Use your head—have fun but play safe. Using your Stilts safely is mostly common sense. Always use in front of Adult Supervision.

1. **Check for hazards before you start.** Never walk without first making sure that the surface is safe—solid, flat, clean, well lit, and dry. The best bet: concrete. Stick to outdoor areas that are free of hazards and give you plenty of room to maneuver.

2. **Hazards to watch out for:**

- **Traffic:** Steer clear of streets, parking lots, and other areas vehicles use.
- **Humans:** Using your Master too close to other people is dangerous and rude.
- **Slippery/Uneven Ground:** Don't try to walk on a surface which is wet, oily, or even lightly covered with sand, gravel, leaves, or litter—you'll greatly reduce the traction of your tip.
- **Steep Inclines:** Remember, you want to maintain a position perpendicular to the ground. If the surface slopes sharply, that's just not possible, and it's far more likely you'll skid sideways and fall.
- **Soft or Weak Surfaces:** Don't walk on plank flooring, lawns, or any other inconsistent surface.

USER Guidelines:

- **Check your Master Stilts before first use and on a regular basis.**
- **NEVER use Master Stilts with bare feet. Always wear athletic shoes.**
- **Do not use your Master Stilts without the rubber tips properly in place.**
- **Store your stilts in a dry and sheltered place.**
- **Never use the stilts on a uneven, sloping and wet surface.**
- **Do not modify or remove any original component parts of the Master Stilts.**

Stay within your abilities. With experience and skill, you'll be able to react to pretty much any situation reflexively. But skill develops slowly, so take your time. As you put in the hours, you'll become instinctively aware of how much traction you have, how to correct for balance, and where you're going to walk. Be prepared to bail out at any time.